




Parts Information:
Floor Cabinet 4 Shelf 2 Door
Model No: SC01.V2



Item	Part No.	Description
1	SC01.V2-A1	Back Panel, Left
2	SC01.V2-A2	Back Panel, Right
3	SC01.V2-B1	Side Panel, Left
4	SC01.V2-B2	Side Panel, Right
5	SC01.V2-C	Cross Member, Inner
6	SC01.V2-D	Bottom Panel
7	SC01.V2-E	Cross Member, Outer
8	SC01.V2-F	Top Panel
9	SC01.V2-G	Shelf
10	SC01.V2-H1	Door, Left

Item	Part No.	Description
11	SC01.V2-H2	Door, Right (c/w Lock)
12	SC03.I	Screw M5 x 30mm (c/w Wing Nut)
13	SC03.J	Locating Piece
14	SC03.K	Insert
15	SC03.L	Plastic Insert
16	SC03.R	Pin
17	SC03.Q	Rubber Bumper
18	SC03.S	Shelf Fastener
--	SC01.V2-R	Lock and Key (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.