



LW718

LED Rechargeable Camping Lantern

Information for use

Intention For Use

Thank you for purchasing the LED Rechargeable Camping Lantern from Streetwize Leisure. This lantern offers reliable, adaptable lighting, making it perfect for camping trips, emergencies, or garden parties. This manual will guide you through setting up and using your new lantern.

Charging the Lantern

1. Locate the charging port on the lantern.
2. Plug the Type-C charging cable into the lantern's charging port.
3. Connect the other end of the cable to a USB power source (e.g., power bank, wall adapter).
4. A charging indicator light will turn on red while charging and will turn green when fully charged (Fig. 1).
5. Charging time may vary depending on the power source.

Note: The USB port can be used to charge other products.

Using the Lantern

1. Press the power button once to turn on the lantern.
2. Each subsequent press of the button will cycle through the brightness modes:
100% -> 50% -> 25% -> Flashing -> Off

Hanging the Lantern

1. The lantern has a built-in hanging hook on the top.
2. Simply clip the hook onto a tent pole, branch, or any other suitable hanging point.

Cleaning and Maintenance

- Wipe the lantern clean with a damp cloth. Do not submerge the lantern in water.
- Store the lantern in a cool, dry place when not in use.



Fig.1

Safety Warnings


- Do not point the light directly into eyes.
- Do not use the lantern while charging.
- Do not disassemble the lantern.
- This product is not intended for children

Technical Support

If you require any technical support for your product within the warranty period, please contact us on support@streetwize.co.uk and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.

WEEE



The WEEE symbol  on this product means that this unit should be ethically dismantled or recycled to minimise environmental impact. Please check with your local authority for more information.

IMPORTANT: ADDITIONAL SAFETY INFORMATION

This device is **NOT** intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are supervised or have been given instruction concerning use of the device by a person responsible for their safety.

Technical Specification

Product name	LED Rechargeable Camping Lantern
Product Code	LW718
Power	4000mAh Li-Ion (2 x 18650 batteries)
LED	3w COB
Lumen	1000lm
Dimensions	21.6 x 10.5 x 9cm
Material	ABS, PC, TPR

