

Concrete Fixing Kit For Speed Bumps

Materials:

Supplied in pairs: Zinc Plated Steel Bolt & Shield



Left – Assembled Right – Unassembled

Instructions For Use:

- 1. Position required number of speed bumps and mark the location of the fixing holes on the surface to be applied to.
- 2. Remove speed bumps and drill holes at the marked positions as follows: Concrete 20mm Diameter Hole Size, Minimum Depth 65mm. The correct fixing for the surface must be used.
- 3. Clean hole of debris.
- 4. Insert bolt shield into hole.
- 5. Reposition units and pass the bolts through the locating holes and screw into the shield.
- 6. Tighten bolt to a torque of: 27NM.

It is the responsibility of the Landowner / Leaseholder to place appropriate signage to indicate the speed limit at which the Speed Bumps should be approached.

Limitations Of Use:

Damage to vehicle components is possible if the speed bumps are approached at speeds higher than recommended.