

## Asphalt Fixing Kit For Speed Bumps

## Materials:

Supplied in pairs: Zinc Plated Steel Bolt Zinc Plated Shield C/W Rubber Collar



Left – Assembled Right – Unassembled

## Instructions For Use:

- 1. Position required number of speed bumps and mark the location of the fixing holes on the surface to be applied to.
- Remove speed bumps and drill holes at the marked positions as follows: Asphalt – 24mm Diameter Hole Size, Minimum Depth 85mm. The correct fixing for the surface must be used.
- 3. Clean hole of debris.
- 4. Insert bolt shield into hole.
- 5. Reposition units and pass the bolts through the locating holes and screw into the shield.
- 6. Tighten bolt to a torque of: 15-20NM.

It is the responsibility of the Landowner / Leaseholder to place appropriate signage to indicate the speed limit at which the Speed Bumps should be approached.

## Limitations Of Use: Damage to vehicle components is possible if the speed bumps are approached at speeds higher than recommended

**Manufacturing For Safety**