

GRIPPS®

GRIPPS® Technical Specification Sheet.

GRIPPS® Pouch Models: H02101, H02102



H02101
Bolt-Safe Pouch
Max Load (D-Ring):
0.7kg / 1.5lbs
Max Load (Pouch):
1.2m / 47"



H02102
Bolt-Safe Rail Bag
Max Load (Pouch):
5.0kg / 11lbs
ANSI/ISEA 121-2018
COMPLIANT

GRIPPS® Pouch

SAFETY INFORMATION

⚠ WARNING Before using the GRIPPS® Pouches, read all provided safety information pertaining to the use of your Dropped Tool Prevention (DTP) device. **FAILURE TO DO SO COULD RESULT IN INJURY OR DEATH.**

The user of a DTP device bears the responsibility of reading all safety information contained herein. Keep this manual for future reference.

Intended Use:

When used properly, the GRIPPS® Pouches can prevent workplace hazards resulting from dropped tools. These may include personal injury and material damage.

GRIPPS® does not approve use of this device for any activities not described in the User Instructions. This device is not intended to be used in any recreational activity, as a personal fall-arrest device or in any other manner not described herein.

⚠ WARNING Misuse of this device could result in serious injury or death.

Adhere to all manufacturer recommendations regarding the operation and maintenance of this device. For additional information, contact GRIPPS® customer support.

Read and adhere to the following in order to ensure correct operational functionality:

- Your DTP should never be used as a personal fall-arrest device or restraint system.
- Do not use this device with tools that exceed the specified maximum load/weight.
- A DTP device used in applications that exceed the limits of operation specified by the manufacturer should be considered unsafe and should be replaced.
- Do not tether a tool over 2.5kg/5.5lbs directly to your clothing or person.
- Inspect your DTP device before each use.
- Ensure the DTP device is securely connected to a load rated tool connector or anchor point before use.
- Inspect any tool connector point before it is connected to the DTP device.
- Modification of the DTP device voids all warranties and violates manufacturer recommendations.
- Do not use a tool that cannot be connected to your DTP in the manner specified by GRIPPS®.
- It is unsafe to extend the length of the DTP product by any means.
- Do not use this product if it will create an unsafe working environment.
- Use extra precaution around moving machinery, moving parts, electrical hazards, extreme temperatures, chemical hazards, or combustion hazards.
- Avoid contact between any connected tethers and rough or sharp edges.
- Regularly inspect the Velcro on the back of the Pouch to ensure they are free from any dust, grime or debris.
- All connected tools and equipment, including connection points, must be compatible for use with this DTP device.

- Always wear appropriate personal protective equipment.
- If a tether has arrested a dropped tool or object, it should be taken out of service and replaced.
- All procedures shown in this instruction are for GRIPPS® Pouch products only.

GENERAL USE AND CARE

GRIPPS® Pouches are designed to safely contain and transport small objects. A 'best in class' self-closure system makes it almost impossible for loose nuts, bolts and other small items to fall out of the pouches. Even when turned upside down and shaken vigorously, the pouches keeps all contents trapped safely inside.


Recommended Use of GRIPPS® Pouches:

1. Both the Bolt-Safe Pouch and Rail Bag can be anchored to a work belt, harness, scaffolding or rails.
2. If anchoring to a tool belt, use a GRIPPS® Econo Belt or Reinforced Synthetic Belt.
3. Use the Bolt-Safe Pouch for holding or transporting loads that weigh up to 2.5kg/5.0lbs.
4. Use the Bolt-Safe Rail Bag for holding or transporting loads that weigh up to 5.0kg/11lbs.
5. Only connect additional tethers to the load rated D-Rings.


Before Use:

Thoroughly inspect your GRIPPS® DTP device before each use. Do not use any component that presents deformities or deterioration.


HOW TO USE / INSTRUCTIONS:




To anchor Bolt-Safe Pouch or Rail Bag to a belt, feed belt through both loops on the rear side of the pouch.



To anchor Bolt-Safe Pouch to a harness, loop the loop and hook strap around the harness and through the plastic buckle.



Then pull the strap tightly and press firmly together to attach.



To anchor Bolt-Safe Pouch or Rail Bag to a rail, pass the loop and hook strap around the rail and through the buckle, pulling tight.

*** NEVER EXCEED MAX LOAD ***

After Use Care:

Clean and inspect the pouch and any connected tethers. For tougher stains, use warm water and a mild soap or detergent. Do not use again until dry.

Store in a clean and dry environment. Proper care will help to ensure that it will operate effectively and extend its service.

GRIPPS®